

Make-A-Berm™ Draining Plug Insert Installation Instructions



1. Determine where you want to install the draining plug section.

Note: We recommend you choose the lowest point of the containment area to facilitate pump free drainage.

2. Using a utility knife, cut and remove a 5" section of your installed Make-A-Berm barrier.



3. Scrap away old caulking with a putty knife.



4. Make sure the foam inserts of your draining plug are firmly against the PVC tubing in the middle.



5. Test fit the draining plug section in the 5" gap of your barrier. The vinyl flaps of your draining plug section should overlap the Make-A-Berm barrier section on both sides.



6. Lift out the draining plug section and apply silicone caulking (sold separately) to the ground where draining plug section will be installed.



7. Apply industrial-strength vinyl cement (sold separately) to the overlapping flaps of your draining plug section.



8. Install the draining plug section into the 5" gap with the nylon cap on the outside of the containment area. Firmly press down to ensure a reliable seal.



Caution: Do not drive or rollover the draining plug section. The weight of vehicles or hand trucks can damage the PVC tubing.

Caution: This product should only be used to drain innocuous fluids, such as rain or snowmelt. Hazardous or contaminated liquids should be collected and disposed of according to federal, state and local regulations.